Translated English of Chinese Standard: QC/T1033-2016

<u>www.ChineseStandard.net</u> → Buy True-PDF → Auto-delivery.

<u>Sales@ChineseStandard.net</u>

QC

AUTOMOBILE INDUSTRY STANDARD OF THE PEOPLE'S REPUBLIC OF CHINA

ICS 43.040.40

T 24

QC/T 1033-2016

Air brake - Performance requirements and bench test methods of external automatic brake adjuster

气压制动器 外置式间隙自动调节装置技术要求及台架试验方法

Issued on: April 05, 2016 Implemented on: September 01, 2016

Issued by: Ministry of Industry and Information Technology of the People's Republic of China

		Technical conditions		2016-09-01
334	QC/T 687-2016	for cylinder body of	QC/T 687-2002	
		motorcycle and	Q0/1 00/ 2002	
		moped engine		22/2 22 2/
335	QC/T 688-2016	General	QC/T 688-2007	2016-09-01
		specifications of		
		motorcycles and		
		mopeds Specification for		2016-09-01
336	QC/T 724-2016	direct current		2010-09-01
		flasher units of	QC/T 724-2004	
		motorcycles and	Q0/1 /21 200 !	
		mopeds		
		Motorcycle and		2016-09-01
227	00/7 750 0040	moped catalytic	QC/T 752-2006,	
337	QC/T 752-2016	converter test	QC/T 751-2006	
		method		
		Motorcycles and		2016-09-01
338	QC/T 753-2016	mopeds - The form	QC/T 753-2006	
		format of technical		
		parameters		
	QC/T 1031-2016	Motorcycle and		2016-09-01
339		moped wheel spline		
		sets Motorcycle and		2016-09-01
340	QC/T 1032-2016	Motorcycle and moped engine		2010-09-01
340	QC/1 1032-2010	camshaft		
		Air brake - External		2016-09-01
		clearance automatic		
	QC/T 1033-2016	adjustment device		
341		technical		
		requirements and		
		bench test methods		
	QC/T 1034-2016	Rectifier bridge for		2016-09-01
342		automotive		
		alternator		
343	QC/T 1035-2016	Electronic throttle		2016-09-01
		body for automobile		
		engine		2016 00 01
344	QC/T 1036-2016	Automobile power inverter		2016-09-01
		High voltage cable		2016-09-01
345	QC/T 1037-2016	for road vehicles		2010-03-01
		TOT TODA VOLIDIOS		

346	QC/T 1038-2016	Automotive Light Emitting Diodes (LEDs) and Modules	2016-09-01
347	QC/T 1039-2016	Solar sensor for automotive air conditioning	2016-09-01
348	QC/T 1040-2016	Motorcycle and moped electric fuel pump	2016-09-01
349	QC/T 1041-2016	Technical requirements for motorcycle evaporative pollutant control systems (devices) for motorcycles and mopeds	2016-09-01
350	QC/T 1042-2016	Motorcycle and moped vibration comfort test method	2016-09-01
351	QC/T 1043-2016	Nylon tube for automotive fuel system	2016-09-01
352	QC/T 1044-2016	Foot pad for automobile	2016-09-01
353	QC/T 1045-2016	Heat-shrinkable tubing for automotive pipe	2016-09-01
354	QC/T 1046-2016	Heat pipe shrinkage for automobile pipeline protection	2016-09-01
355	QC/T 1047-2016	City bus plastic seat	2016-09-01
356	QC/T 1048-2016	Bus emergency hammer	2016-09-01
357	QC/T 1049-2016	Technical requirements and test methods for matching of automobile rack and pinion hydraulic power steering system	2016-09-01

Table of Contents

Foreword	8
1 Scope	c
2 Normative references	
3 Terms and definitions	
4 Technical requirements	10
5 Test related requirements	11
6 Test methods	12

Air brake - Performance requirements and bench test methods of external automatic brake adjuster

1 Scope

This Standard specifies the terms and definitions, technical requirements, test related requirements and bench test methods for external automatic brake adjuster of car and trailer air drum brakes.

This Standard is applicable to external automatic brake adjuster of car and trailer air drum brakes (hereinafter referred to as "automatic brake adjuster").

2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

GB/T 175, General purpose Portland cement

GB/T 5620, Road vehicles - Braking of automotive vehicles and their trailers - Vocabulary

QC/T 32-2006, Test methods of air cleaners for automobiles

3 Terms and definitions

The terms and definitions defined in GB/T 5620 as well as the followings apply to this Standard.

3.1 rate torque, T_e

the maximum working torque value of the worm gear rotating by the brake chamber pushing rod under the rated working pressure and the rated working pressure

NOTE: The unit of rated torque is N•m.

- 150 mm arm length), and zeroing the measuring device. Then apply the same test torque in the opposite direction to 6.2.2, while recording the displacement of the displacement measuring device.
- **6.2.4** Rotate the worm shaft to turn the worm gear 72°±3°, then repeat at this position 6.2.2 and 6.2.3.
- **6.2.5** Repeat 6.2.4 for a total of 3 times.

6.3 High-low temperature test

- **6.3.1** Immerse the automatic brake adjuster in a closed tank and apply a constant pressure of (21±5) kPa inside the tank.
- **6.3.2** Remove the automatic brake adjuster from the water after 24h (do not dry). Immediately install it on the test fixture as follows:
 - a) install and adjust the automatic brake adjuster according to the product technical documentation requirements;
 - b) when the automatic brake adjuster is in the brake release state, the residual torque it receives shall be (22.5 ±11.5) N•m;
 - c) when the torque applied by the automatic brake adjuster is 200 N•m, the brake chamber push rod stroke shall be greater than the upper limit of the maximum brake interval of the automatic brake adjuster.
- **6.3.3** Place the automatic brake adjuster and test fixture at least for 16 h in an environmental chamber at an ambient temperature of (-40±2)°C.
- **6.3.4** At the end of the installation, the automatic brake adjuster is still subjected to 3 braking tests with a test torque of 200 N•m under this ambient temperature condition. Observe and record the operation of the automatic brake adjuster and the brake chamber push rod stroke for each brake.
- **6.3.5** Adjust the automatic brake adjuster to the initial state before the low temperature test. The sample and test fixture are then allowed to stand for at least 16h in an environmental chamber at an ambient temperature of (80±3)°C.
- **6.3.6** At the end of the placement, the automatic brake adjuster is still subjected to 100 braking tests with a test torque of 200 N•m under this ambient temperature condition. Observe and record the operation of the automatic brake adjuster and the stroke of the air chamber pusher during each braking.

6.4 Corrosion resistance

6.4.1 Install the automatic brake adjuster on the test fixture in the salt bath according to the technical documentation requirements of the product.

6.5.7 After the test, adjust the torque according to 6.1.

6.6 Dust test

- **6.6.1** The automatic brake adjuster sample is mounted on the test fixture in the dust chamber with a cavity size of approximately 900mm × 900mm as required by the product technical documentation. The distance between the surface of the sample and the chamber shall not be less than 150mm.
- **6.6.2** Perform 100 brake tests at a test torque of 0.2T_e or until the chamber push stroke is stable.
- **6.6.3** Perform braking at a test torque of 0.2T_e, and the displacement at the arm length of 150 mm shall be recorded as the initial stroke.
- **6.6.4** Spread 4.5 kg of cement in accordance with GB 175 evenly on the bottom of the box.
- **6.6.5** Carry out 5000 brake tests according to the test torque of 0.2T_e, and the working time of each brake shall be the same as 6.4.8.
- **6.6.6** During the test, in order to simulate the brake lining wear, the brake gap shall be increased every 160 times of brake tests are performed, so that the angle of the automatic brake adjuster is increased by 0.5°.
- **6.6.7** During the test, the cement is stirred once with compressed air or blower every 15 minutes. Each stirring time is 2s, and the cement dust shall be filled into the dust box when stirring.
- **6.6.8** During the test, if the working stroke measured at the arm length of 150 mm from the center of the worm gear of the automatic adjustment device exceeds the initial stroke by 6.2 mm, the automatic adjustment mechanism of the gap is considered to be invalid, and the test shall be terminated.
- **6.6.9** After the test is finished, repeat the adjustment torque according to 6.1.

6.7 Durability test

6.7.1 Gear pair integrity

- **6.7.1.1** Install the automatic brake adjuster on the test bench according to the product technical documentation requirements.
- **6.7.1.2** Adjust the angle between the brake chamber push rod and the arm of the automatic brake adjuster, so that when the test load reaches the rated torque, the brake chamber push rod and the arm of the automatic brake adjuster are in a vertical state, that is, the angle between the push rod and the arm is 90°±3°.

This is an excerpt of the PDF (Some pages are marked off intentionally)

Full-copy PDF can be purchased from 1 of 2 websites:

1. https://www.ChineseStandard.us

- SEARCH the standard ID, such as GB 4943.1-2022.
- Select your country (currency), for example: USA (USD); Germany (Euro).
- Full-copy of PDF (text-editable, true-PDF) can be downloaded in 9 seconds.
- Tax invoice can be downloaded in 9 seconds.
- Receiving emails in 9 seconds (with download links).

2. https://www.ChineseStandard.net

- SEARCH the standard ID, such as GB 4943.1-2022.
- Add to cart. Only accept USD (other currencies https://www.ChineseStandard.us).
- Full-copy of PDF (text-editable, true-PDF) can be downloaded in 9 seconds.
- Receiving emails in 9 seconds (with PDFs attached, invoice and download links).

Translated by: Field Test Asia Pte. Ltd. (Incorporated & taxed in Singapore. Tax ID: 201302277C)

About Us (Goodwill, Policies, Fair Trading...): https://www.chinesestandard.net/AboutUs.aspx

Contact: Wayne Zheng, Sales@ChineseStandard.net

Linkin: https://www.linkedin.com/in/waynezhengwenrui/

----- The End -----