Translated English of Chinese Standard: GBZ/T276-2016

www.ChineseStandard.net → Buy True-PDF → Auto-delivery.

Sales@ChineseStandard.net

**GBZ** 

# NATIONAL OCCUPATIONAL HEALTH STANDARD OF THE PEOPLE'S REPUBLIC OF CHINA

ICS 13.100

C 52

GBZ/T 276-2016

# Fit Test Panels for Self-inhalation Air-purifying Respiratory Protective Equipment

自吸过滤式呼吸防护用品适合性检验颜面分栏

Issued on: November 4, 2016 Implemented on: May 1, 2017

Issued by: National Health and Family Planning Commission of the

People's Republic of China

## **Table of Contents**

Foreword	. 3
1 Scope	. 4
2 Normative References	. 4
3 Terms and Definitions	. 4
4 Binary Fit Test Panel for Adults	. 5
Appendix A (normative) A Statement of Correct Application of This Standard.	. 7

# Fit Test Panels for Self-inhalation Air-purifying Respiratory Protective Equipment

# 1 Scope

This Standard stipulates the fit test panels for the design and inspection of self-inhalation air-purifying respiratory protective equipment.

This Standard is applicable to the design, selection and inspection of self-inhalation air-purifying respiratory protective equipment.

## 2 Normative References

The following documents are indispensable to the application of this document. In terms of references with a specified date, only versions with a specified date are applicable to this document. In terms of references without a specified date, the latest version (including all the modifications) is applicable to this document.

GB/T 5703 Basic Human Body Measurements for Technological Design

GB/T 18664-2002 Selection, Use and Maintenance of Respiratory Protective Equipment

## 3 Terms and Definitions

The following terms and definitions are applicable to this document.

#### 3.1 Self-inhalation Air-purifying Respiratory Protective Equipment

Self-inhalation air-purifying respiratory protective equipment refers to air-purifying respiratory protective article that overcomes resistance of components through the wearer's respiration.

#### 3.2 Bizygomatic Breadth

Bizygomatic breadth refers to the straight-line distance between the left and the right zygomatic points.

### 3.3 Face Length / Nasion-menton

Face length / nasion-menton refers to the distance between the nasion and the chin point.

#### 3.4 Fit Test

Fit test refers to the method for testing the suitability of a certain type of sealing respiratory protective equipment for specific users.

#### 3.5 Face-seal Check

Face-seal check refers to a method of tightness inspection performed by the user of respiratory protective equipment to ensure that sealing face mask is worn in the correct position.

# 4 Binary Fit Test Panel for Adults

### 4.1 Principle of Fit Test Panel

The indicators of fit test panel are face length / nasion-menton and bizygomatic breadth. The measurement of face length / nasion-menton and bizygomatic breadth is shown in GB/T 5703. In accordance with the two indicators: face length / nasion-menton and bizygomatic breadth of adults, divide them into 10 facial types, number them by #1 ~ #10. The coverage of the fit test panel is above 95%, and the coverage of the various facial types is larger than 2%.

## 4.2 Range of Facial Types

In terms of head-face binary fit test panel, the range of bizygomatic breadth is  $127.5 \text{ mm} \sim 158.5 \text{ mm}$ ; the range of face length / nasion-menton is  $96.5 \text{ mm} \sim 132.5 \text{ mm}$ .

#### 4.3 Method of Fit Test Panel

Binary fit test panel for adults complies with the actually measured face length / nasion-menton and bizygomatic breadth. See Figure 1 for facial types.

### 4.4 Application of Fit Test Panel

When performing fitness test of self-inhalation air-purifying respiratory protective equipment, select testers that meet the various facial types in the sub-column of Figure 1. Please refer to Appendix A for the method of application. Individuals may base on the facial types to select a corresponding model of self-inhalation air-purifying respiratory protective equipment. Before use, the wear tightness inspection shall be performed, then, the fitness test shall be conducted, so as to guarantee the effect of self-inhalation air-purifying respiratory protective equipment.

## This is an excerpt of the PDF (Some pages are marked off intentionally)

## Full-copy PDF can be purchased from 1 of 2 websites:

## 1. https://www.ChineseStandard.us

- SEARCH the standard ID, such as GB 4943.1-2022.
- Select your country (currency), for example: USA (USD); Germany (Euro).
- Full-copy of PDF (text-editable, true-PDF) can be downloaded in 9 seconds.
- Tax invoice can be downloaded in 9 seconds.
- Receiving emails in 9 seconds (with download links).

## 2. <a href="https://www.ChineseStandard.net">https://www.ChineseStandard.net</a>

- SEARCH the standard ID, such as GB 4943.1-2022.
- Add to cart. Only accept USD (other currencies https://www.ChineseStandard.us).
- Full-copy of PDF (text-editable, true-PDF) can be downloaded in 9 seconds.
- Receiving emails in 9 seconds (with PDFs attached, invoice and download links).

Translated by: Field Test Asia Pte. Ltd. (Incorporated & taxed in Singapore. Tax ID: 201302277C)

About Us (Goodwill, Policies, Fair Trading...): <a href="https://www.chinesestandard.net/AboutUs.aspx">https://www.chinesestandard.net/AboutUs.aspx</a>

Contact: Wayne Zheng, Sales@ChineseStandard.net

Linkin: <a href="https://www.linkedin.com/in/waynezhengwenrui/">https://www.linkedin.com/in/waynezhengwenrui/</a>

---- The End -----